

ZEPHIR®

EPIULATOR - ELECTRIC SHAVER 2 IN 1

ZHB666




INSTRUCTION MANUAL

INTRODUCTION

With this epilator, you can remove unwanted hairs quickly, easily and effectively. And you can feel comfortable and less painful than ever. If you use the appliance regularly (every 4 weeks), the result is a silky-smooth skin and a hair growth reduction of up to 50%. This epilator is suitable for all body parts and comes with a sensitive area cap that has been specially developed for epilating sensitive areas (underarms and bikini line). The rapidly rotating epilating discs catch even the shortest hairs and pull them out by the roots. As a result, your skin stays smooth for up to four weeks and regrowth is soft and downy. The fashionable LED light can clearly and easily see the results.

DESCRIPTION



- A.Epilating head
- B.Release button
- C.Switch
- D.Transparent cover
- E.Shaving head
- F.Fashionable LED light
- G.Indicator light
- H.Adaptor
- I.Cleaning brush

IMPORTANT

Read this user manual carefully before you use the appliance and save it for future reference.

1. Keep the appliance and adaptory dry
2. Do not use the appliance near or over a washbain or bath filled with water.
3. Do not use the appliance in the bath or in the shower.

WARNING

1. Do not place heavy objects on the cables or heat sources close to them . The cables may be damaged;
2. This product is intended solely for domestic use;
3. Before carrying out any cleaning or maintenance, disconnect the appliance from the mains by removing the plug.
4. Do not use aerosols sprays (eg . insecticides , hair spray , etc.), it may cause damage to the housing;
5. In case of abnormal situations immediately turn off the power and contact your dealer or service center;
6. Do not use this unit connected to programmers, external timer , remote control system of separate timer or any other device that can switch automatically;
7. Do not use power sockets flying or damaged cables;
8. Do not attach safety switches with tape, for fire hazard;
9. It is absolutely prohibited to disassemble or repair the unit by the danger of electric shock if necessary contact your dealer or service center;
10. Do not use the appliance near a bathtub, shower, swimming pool (including the step of charging the battery);
11. Do not use the machine near flammable objects;
12. Do not insert objects through the slots of the unit;
13. Before connecting to the mains supply, make sure the voltage is correct as reported on the label of the product and that the installation complies with current regulations;
14. Do not touch the power connection with wet hands;
15. Do not use the product for purposes other than those for which it was built;
16. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
17. The cable can not be replaced. If the adapter power cord is damaged the appliance should be scrapped;
18. Children should be supervised to ensure that they do not play with the appliance;
19. Only use the appliance in combination with the adaptor supplied (LY045 030 0300E)
20. Do not use the adapter for other purposes; suited to the single charge of the batteries (rechargeable batteries) unit model ZHB666;
21. Charging should be done in well-ventilated environments;
22. For internal use only;
23. Check if the mains voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.
24. Do not use the appliance if the adaptor or the appliance itself is damaged.

CAUTION

1. Only epilate the underarms and bikini line with the sensitive area cap attached.
2. To prevent damage and injuries, keep the running appliance away from the scalp hair, eyebrows, eyelashes, clothes, threads, cords, brushes, etc.
3. Do not use the appliance on irritated skin or skin with varicose veins, rashes, spots, moles (with hairs) or wounds without consulting your doctor first. People with a reduced immune response or people who suffer from diabetes mellitus, haemophilia or immunodeficiency should also consult their doctor first.
4. Your skin may become a little red and irritated the first few times you use the epilator. This phenomenon is absolutely normal and quickly disappears. As you use the appliance more often, your skin gets used to epilation, skin irritation decreases and regrowth becomes thinner and softer. If the irritation has not disappeared within three days, we advise you to consult a doctor.
5. Always check the shaving head before you use the appliance. Do not use the shaving head if the foil is damaged, as this may cause injury.
6. This appliance contains NIMH rechargeable batteries. So you should dispose it properly in order to harm the environment.
7. Do not expose the appliance to temperatures lower than 5°C or higher than 35°C.
8. Regular cleaning and proper maintenance ensure optimal results and a long life for the appliance.

CHARGING

This appliance can be directly charged from the adaptor. (Fig.2) Charge the batteries at least 10 hours before you use the appliance for a cordless operating time of up to 40 minutes. Do not charge the appliance for more than 24 hours. Make sure the appliance is switched off while charging.

USING THE EPIULATOR

Epilator is easier just after a bath or shower. Make sure your skin is completely dry when you start to epilate. When you use the appliance for the first time, we advise you to try it out on an area with only light hair growth. This helps you get accustomed to the epilation process. For optimal epilating results, the hairs should not be longer than 10mm.

To epilate longer hairs:

Shorten the hairs to a maximum length of 10mm with a trimmer. In this case, you can start to epilate right away.

Epilating the underarms and bikini line:

This makes the appliance ideal for epilating the more delicate areas of the body, such as the underarms and bikini line.

1. Switch on the appliance (select speed 2) (Fig.2)
2. Stretch the skin with your free hand.
3. Place the appliance perpendicularly onto your skin, with the on/off slide pointing in the direction in which you are going to move the appliance.
4. Move the appliance slowly over the skin, against the direction of the hair growth.
Epilate your bikini line as shown in the figure Fig.6
Epilate your underarms as shown in the figure Fig.5
5. Remove the sensitive area cap from the epilator after use.

SHAVING

You can use the shaving head to shave sensitive body parts, such as your underarms and bikini line. With the shaving head, you obtain a smooth result in a comfortable and gentle way.

1. Press the release button and pull the epilating head off the appliance (Fig.8)
2. Place the shaving head on the appliance and press it onto the appliance until it snaps home ("click")
3. Switch on the appliance.
4. Placing the shaving head onto your skin and move the appliance slowly and smoothly against the direction of hair growth.

CLEANING AND MAINTENANCE


Never put the adaptor or the appliance itself into water.

Do not use any corrosive detergents, scouring pads or cloths, petrol, acetone, etc. to clean the appliance.

Cleaning the epilating head and shaving head.

Clean the epilating head and shaving head after every use.

1. Make sure the appliance is switched off and disconnected from the mains.
2. Remove the epilating head and shaving head.
3. Clean all accessible parts, including the bottom of the epilating head and the epilating discs, with the brush (Fig.10)
4. You can also rinse the epilating head and shaving head (not the appliance) under the tap to clean it more thoroughly (Fig.11).
5. Do not exert pressure on the shaving foil to avoid damage.



Italiano



Trattamento del dispositivo elettrico od elettronico a fine vita (Applicable in tutti i paesi dell'Unione Europea e in quelli con sistema di raccolta differenziata)

Questo simbolo sul prodotto o sulla confezione indica che il prodotto non deve essere considerato come un normale rifiuto domestico, ma deve invece essere consegnato ad un punto di raccolta appropriato per il riciclo di apparecchi elettrici ed elettronici. Assicurandovi che questo prodotto sia smaltito correttamente, voi contribuirete a prevenire potenziali conseguenze negative per l'ambiente e per la salute che potrebbero altrimenti essere causate dal suo smaltimento inadeguato. Il riciclaggio dei materiali aiuta a conservare le risorse naturali. Per informazioni più dettagliate circa il riciclaggio di questo prodotto, potete contattare l'ufficio comunale, il servizio locale di smaltimento rifiuti oppure il negozio dove l'avete acquistato.

Ciunque abbandona o cestina questo apparecchio e non lo riporta in un centro di raccolta differenziata per rifiuti elettrici-elettronici è punito con la sanzione amministrativa pecunaria prevista dalla normativa vigente in materia di smaltimento abusivo di rifiuti.

English



Disposal of old electrical & electronic equipment (Applicable in the European Union and other European countries with separate collection systems)

This symbol on the product or in its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Français



Traitements des appareils électriques et électroniques en fin de vie (Applicable dans les pays de l'Union Européenne et aux autres pays européens disposant de systèmes de collecte sélective)

Ce symbole, apposé sur le produit ou sur son emballage, indique que ce produit ne doit pas être traité avec les déchets ménagers. Il doit être remis à un point de collecte approprié pour le recyclage des équipements électriques et électroniques. En s'assurant que ce produit est bien mis au rebut de manière appropriée, vous aiderez à prévenir les conséquences négatives potentielles pour l'environnement et la santé humaine. Le recyclage des matériaux aidera à conserver les ressources naturelles. Pour toute information supplémentaire au sujet du recyclage de ce produit, vous pouvez contacter votre municipalité, votre déchetterie ou le magasin où vous avez acheté le produit.

Español



Tratamiento de los equipos eléctricos y electrónicos al final de su vida útil (Aplicable en la Unión Europea y en países europeos con sistemas de recogida selectiva de residuos)

Este símbolo en su equipo o su embalaje indica que el presente producto no puede ser tratado como residuos domésticos normales, sino que deben entregarse en el correspondiente punto de recogida de equipos eléctricos y electrónicos. Asegurándose de que este producto es desecharlo correctamente, Ud. Está ayudando a prevenir las consecuencias negativas para el medio ambiente y la salud humana que podrían derivarse de la incorrecta manipulación de este producto. El reciclaje de materiales ayuda a conservar las reservas naturales. Para recibir información detallada sobre el reciclaje de este producto, por favor, contacte con su ayuntamiento, su punto de recogida más cercano o el distribuidor donde adquirió el producto.

Deutsch



Entsorgung von gebrauchten elektrischen und elektronischen Geräten (Anzuwenden in den Ländern der Europäischen Union und anderen europäischen Ländern mit einem separaten Sammelsystem für diese Geräte)

Das Symbol auf dem Produkt oder seiner Verpackung weist darauf hin, dass dieses Produkt nicht als normaler Haushaltsabfall zu behandeln ist, sondern an einer Annahmestelle für das Recycling von elektrischen und elektronischen Geräten abgegeben werden muss. Durch Ihren Beitrag zum korrekten Entsorgen dieses Produkts schützen Sie die Umwelt und die Gesundheit Ihrer Mitmenschen. Umwelt und Gesundheit werden durch falsches Entsorgen gefährdet. Materialrecycling hilft den Verbrauch von Rohstoffen zu verringern. Weitere Informationen über das Recycling dieses Produkts erhalten Sie von Ihrer Gemeinde, den Kommunalen Entsorgungsbetrieben oder dem Geschäft, in dem Sie das Produkt gekauft haben.

Imported by Westim S.p.A.
Via Roberto Bracco 42/E, 00137 Rome, Italy
Phone: +39 06 8720311
Mail: info@westim.it
Made in China

